

EFFECTIVE:
JULY 1, 2008

PARTS LIST FOR E-100Z AND E-100HZ SHAFT-SEAL ASSEMBLY

<u>PART #</u>	<u>NAME OF PART</u>
E-100Z	* SHAFT-SEAL ASSEMBLY
E-100HZ	* SHAFT-SEAL ASSEMBLY
E-7	MAIN SHAFT
E-7H	MAIN SHAFT
E-12	LARGE SEAL
E-13	SMALL SEAL
E-18	SEAL DRIVE PIN
E-23	SEAL SPRING
E-14SS	SEAL RING
203SFZ	BALL BEARING
203SFZ-8	BALL BEARING
5 KEY	SHAFT KEY FOR DRIVE GEAR
5100-66PP	RETAINER RING
5160-66PP	RETAINER RING
6227-14	* O-RING
6227-27	* O-RING
61 KEY	KEY

- * **When ordering new or exchange shaft-seal assemblies, the liquid being pumped, model number, and serial number of the pump must be given.
(See metal name plate on pump for this information)**

NOTE: While shaft-seal assembly parts may be ordered individually for pumps used with non-hazardous liquid, we strongly advise against attempting to make repairs in the field. Instead, new or exchange shaft-seal assemblies are available as noted.

We will not ship individual shaft-seal parts for pumps handling hazardous liquids such as LP-GAS or Anhydrous Ammonia within the U.S.A.